



Pictured: Main overpressure (OP) relief valve as seen on MCH6 compressor.

SKU 504 "OP" VALVE

**DO NOT EXCEED MAXIMUM
PRESSURE OF COMPRESSOR**

504 maximum operating pressure:
6000 psi (414 bar)

504 set pressure range:
900–6000 psi (62–414 bar)

HOW TO CHANGE OP PRESSURE

- Loosen locking nut to change pressure
- Clockwise increases OP valve pressure
- Counterclockwise reduces pressure
- Adjust using a 5/16" Allen wrench