





NUVAIR O₂ QUICKSTICK TROUBLESHOOTING TREE

· For Quicksticks Manufactured After August 2021 ·





FOOTNOTES/DEFINITIONS

¹POT/KNOB: Potentiometer/Knob (Part #F, above).

The rotating knob turns the O₂ Quickstick on/off and calibrates the sensor.

²9-volt Battery Harness (Part #D, above).

³PCB: Printed Circuit Board.

⁴CDB: Circular Distribution Board (Part #B, above).

RELATED VIDEOS

<https://www.youtube.com/@NuvairCompressors>

O₂ Quickstick Quick Start · <https://youtu.be/ZsPwKBIQOe8>

O₂ Quickstick Sensor Replacement · <https://youtu.be/4GILLmdNywk>

O₂ Quickstick Battery Change · <https://youtu.be/QgywZmQlhBk>

O₂ Quickstick CDB Replacement · <https://youtu.be/ClbRPcKomtQ>